

INSTALLATION GUIDE

LED Cooler Light



RISK OF ELECTRIC SHOCK

- All electrical connections must be in accordance with local and National Electric code (N.E.C.) standards.
- If unfamiliar with proper electrical wiring connections, obtains the service from a qualified electrician.


RISK OF FIRE

- Keep combustibles and other easy-burn materials away from lights.
- The maximum ambient temperature is 45°C .Do not operate at higher temperature.

CAUTION: Turn off the the circuit breaker before installation to prevent electric shock.




SPECIFICATIONS



Model No.	HL-CL-32W6K	HL-CL-40W6K	HL-CL-48W6K
Size	4ft	5ft	6ft
Dimensions	59.06" x 1.1" x 1.1"	59.06" x 1.1" x 1.1"	70.87" x 1.1" x 1.1"

ACCESSORIES BAG INCLUDES:



Power Feed Cable x 1



End Cap*1



T-cable x 1



Mounting Clips x 2





Screws*2

*Pictures and diagrams in this IM are for illustrative purpose only.

PLEASE READ CAREFULLY BEFORE INSTALLATION
Save these instructions as it may be need later.

INSTALLATION INSTRUCTION

SURFACE MOUNT INSTALLATION




OPERATING GUIDE

WIRING GUIDE

Black/Live

White/Neutral



CONNECTION INSTALLATION

1. Please find the connector in the accessories bag.
2. Plug the connector into the tube.


Note:

For safety standard,

please do not connect more than 5pcs 2ft,3ft LED lamp in a row;

do not connect more than 4 pcs 4ft LED lamp in a row;

do not connect more than 3 pcs 5ft,6ft,8ft LED lamp in a row;



WARRANTY

5-YEAR LIMITED WARRANTY: This product is guaranteed to be free from defects in material and workmanship for a period of 5 years from the date of original purchase. Instances of normal wear and tear, damage caused by abuse, misuse, alteration or failure to follow instructions or proper maintenance protocols are not covered

*Pictures and diagrams in this IM are for illustrative purpose only.